


WARNING: FOLD MACHINE VERY CAREFULLY THE FIRST TIME AFTER FITTING ATTACHMENTS, LOOK FOR FOULS

PRESS WHEEL ASSEMBLY WITH HARROW TELE MOUNTING

1. Determine length of RHS (2) and quantity of presswheels (1) to match existing harrow gang. Ensure there is 5 cm between ends of adjacent RHS (2) for correct function.
2. Attach dropper (8) and determine breakout clearance behind last rank of tines with RHS (2) at 42 cm to 45 cm from bottom of RHS (2) to ground level.
ENSURE DISTANCE FROM CENTRE OF TELEARM PIVOT PIN AS SHOWN BELOW DOES NOT EXCEED 120 cm
3. Fix outrigger (7). Fit RHS (2) above or below it as determined in step 2.
4. Position and fix press wheel assemblies in line with tines. If Vee bolt interferes with outrigger (7), reverse offset of outrigger (7) relative to dropper (8).
5. Adjust down pressure as required.



REF	QTY	PART No	DRG SIZE	DESCRIPTION
10	2	PI6LYNCH		LYNCH PIN
9	1	HS3030		LOCKING PIN
8	1	TP4070		DROPPER
7	2	TP4080		OUTRIGGER
6	4	UB4003		U BOLT - M16
5	12	WA16HS		SPRING WASHER - M16
4	12	NU16NZP		NUT - M16
3	2	UB4002		U BOLT - M16
2	1	RH30054		05 x 05 x 4 RHS LENGTH 45 REED
1	4R	PA4110/4130		PRESS WHEEL ASSEMBLY

AGMASTER
2067 HARSHALL ST. COLLIE WA 6225

ASSY INSTRUCTIONS | A11070
TELE PRESS WHEELS